

Assembling instruction

POOL CAMPING

Take off all pieces from the original packing, cages and cardboard

- 1** Place the cabinet upside-down and install the legs, bolts are inside the box—remember to fix the feet levellers
- 2** Turn the cabinet back on straight position. Now you have to install the slate. Take off the bolts all around the top frame and lift it off. Insert the slate inside the internal wood guide, put the top frame back in position, fix the bolts and tight them hard. Cover the bolts with their black plastic cups .
- 3** Warning: the black cups are in a plastic bag fixed on a wood support inside the table, remember to take them off before inserting the slate.
- 4** Now you have to level the pool by adjusting the feet. A level will help you to do a better job.

The Pool is ready to play. Have fun!!!

TRANSFORM A COIN MECH TABLE TO A FREE PLAY

Transforming a coin mech in a Free play is easy done! You just have to take off the ball releaser from the mechanism. You can do it from the front panel on the long side of the Pool or (suggested way) from the inside, in this case you have to take off the slate. In the picture you can see the side of the mechanism. Just unscrew the two bolts pointed. Then slide off the releaser.

